

KD-CHECK PREW-AS

Alkaline Pre- and Post-Cleaner

Product Description

- Aqueous and strongly alkaline pre- and post-cleaner for difficult to remove contaminants from component surfaces
- Ideally suited as universal pre-cleaner with high cleaning performance
- Application: spraying, dipping, manually
- Composed of anionic/nonionic surfactants, additives, defoamers, solubilizers
- Concentration: 1:5 to 1:150

Product Specifications

- Appearance: turbid liquid
- Density (20 °C): 1.05 g/ml approx.
- pH value: > 13
- Solubility: completely miscible with water
- Shelf life: 3 years
- Storage temperature: 5 °C to 45 °C



Before using KD-CHECK PREW-AS, resistance tests must be carried out and we recommend determining the required application concentration by appropriate preliminary tests. After cleaning, the components must be thoroughly rinsed with water. If you have any questions, please do not hesitate to contact us.

For the Environment

- Free of phosphates



Packaging

- 1 l bottle (order no.: 9980.101)
- 5 l canister (order no.: 9980.102)
- 10 l canister (order no.: 9980.103)
- 25 l canister (order no.: 9980.125)
- 200 l barrel (order no.: 9980.104)
- 1000 l IBC (order no.: 9980.105)

Disposal

Undiluted KD-CHECK PREW-AS must be diluted before disposal. The local discharge regulations must be observed.

Work Safety

The product is corrosive, therefore hand and eye protection must be worn. All information on work safety, personal protective equipment and measures to be taken in case of accidents can be found in the Safety Data Sheet.

KARL DEUTSCH Prüf- und Messgerätebau GmbH + Co KG · Otto-Hausmann-Ring 101 · 42115 Wuppertal · Germany
Phone +49 202 7192 0 · info@karldeutsch.de · www.karldeutsch.de

The Technical Data Sheet provides recommendations and possible examples. Obligations or liability cannot be derived therefrom. The information is based on our current knowledge and does not release the user from personal responsibility. The object conditions and product suitability must be checked professionally and appropriately. Take into account the information given in the Safety Data Sheet. We are happy to provide test samples for trials. Issue: 11 June 2026